



Applications for #72020 X-Cargo Sport 20, #72016 X-Cargo X-Treme & #72003 Thule Evolution

Note: These cargo carriers can not be attached directly to vehicles not listed below. **For additional fit options, see SportRack Application Guide.**

ACURA		Fit
'07-09	MDX w/ Factory Rack	✓+72314
'01-06	MDX w/ Factory Rack	✓
'07-09	RDX w/ Factory Rack	✓
AUDI		Fit
'88-92	100 Wagon	✓+72314
'88-92	200 Wagon	✓+72314
'78-83	5000	✓+72314
'97-08	A4 (Avant) Wagon w/ Factory Rack	✓+72314
'01-05	A6 Allroad Wagon w/ Factory Rack	✓+72314
'99-05	A6 Wagon w/ Factory Rack	✓+72314
'93-94	Quattro 100 Wagon w/ Factory Rack	✓+72314
'01-08	S4 Wagon w/ Side Rails	✓+72314
02-04	S6 Wagon w/ Factory Rack	✓+72314
BMW		Fit
'00-09	3 Series Wagon w/ Factory Rack	✓+72314
'99-03	5 Series Wagon w/ Factory Rack	✓+72314
'04-09	X3 w/ Factory Rack	✓+72314
'07-09	X5 w/ Factory Raised Rails	✓+72314
BUICK		Fit
'82-96	Century Wagon w/ Factory Rack	✓+72314
'77-90	Electra Estate Wagon w/ Factory Rack	✓+72314
'08-09	Enclave w/ Factory Crossbars	✓[1]
'77-89	LeSabre Estate Wagon w/ Factory Rack.	✓+72314
'04-07	Ranier w/ Factory Rack	✓
'02-07	Rendezvous w/ Factory Rack	✓
'92-96	Roadmaster Wagon w/ Factory Rack	✓
'82-89	Skyhawk Wagon	✓+72314
'05-07	Terraza w/ Factory Rack	✓+72314

CADILLAC		Fit
'99-09	Escalade w/ Factory Rack	✓
'03-09	Escalade ESV w/ Factory Rack	✓
'02-09	Escalade EXT Pickup w/ Factory Rack	✓
'04-09	SRX w/ Factory Rack (Except Sport Model)	✓+72314
CHEVROLET		Fit
'90-05	Astro Van w/ Factory Rack	✓
'85-89	Astro Van w/ Factory Rack	✓
'02-09	Avalanche w/ Factory Rack	✓
'95-05	Blazer 2DR w/ Factory Rack	✓
'95-04	Blazer 4DR w/ Factory Rack	✓
'77-96	Caprice Wagon w/ Factory Rack	✓+72314
'82-87	Cavalier Wagon	✓
'82-90	Celebrity Wagon w/ Factory Rack	✓+72314
'05-09	Equinox	✓
'92-94	Full Size Blazer w/ Factory Rack	✓
'06-09	HHR w/ Factory Rack	✓
'90-96	Lumina APV Van w/ Factory Rack	✓
'05-08	Optra Wagon w/ Factory Rack (Canada Only)	✓
'93-94	S-10 Blazer 2DR w/ Factory Rack	✓
'85-90	S-10 Blazer 2DR w/ Factory Rack	✓
'91-94	S-10 Blazer 4DR w/ Factory Rack	✓+72314
'85-90	S-10 Blazer 4DR w/ Factory Rack	✓
'92-09	Suburban w/ Factory Rack	✓
'79-91	Suburban w/ Factory Rack	✓
'01-09	Suburban Z71 w/ Factory Rack	✓
'95-99	Tahoe 2DR w/ Factory Rack	✓
'95-09	Tahoe 4DR w/ Factory Rack	✓
'01-06	Tahoe Z71 w/ Factory Rack	✓
'99-04	Tracker 4DR w/ Factory Rack	✓+72314

✓+72314 = The #72314 Rack System is needed to allow these carriers to be used. SportRack #72320 may be substituted for #72314 if available.

✓[1] = Only carriers #72003/72016 will fit this vehicle.

If additional information is needed, please call Customer Service at 1-800-561-0716.



Applications for #72020 X-Cargo Sport 20, #72016 X-Cargo X-Treme & #72003 Thule Evolution

Note: These cargo carriers can not be attached directly to vehicles not listed below. **For additional fit options, see SportRack Application Guide.**

CHEVROLET (continued)		Fit
'96-98	Tracker 4DR w/ Factory Rack	✓+72314
'02-09	TrailBlazer 4DR w/ Factory Rack	✓
'02-06	TrailBlazer EXT 4DR w/ Factory Rack	✓
'05-08	Uplander w/ Factory Rack	✓+72314
'97-04	Venture w/ Factory Rack	✓
CHRYSLER		Fit
'88-95	Caravan/Gr. Caravan w/rack	✓
'07-09	Aspen	✓
'04-08	Pacifica w/ Factory Rack	✓
'01-09	PT Cruiser w/ Factory Rack	✓
'89-09	Town & Country w/ Factory Rack	✓
'01-03	Voyager / Grand Voyager w/ Factory Rack	✓
DAEWOO		Fit
'98-02	Nubira Wagon w/ Factory Rack	✓+72314
DODGE		Fit
'07-09	Caliber / SRT4 w/ Factory Rack	✓[1]
'84-09	Caravan / Grand Caravan w/ Factory Rack	✓
'92-94	Colt Wagon	✓
'88-91	Colt Vista Wagon w/ Factory Rack.	✓+72314
'98-02	Durango / Durango Sport w/ Factory Rack	✓
'08-09	Journey w/ Factory Rack	✓
'94-99	Neon 4DR w/ Factory Rack	✓+72314
FORD		Fit
'83-90	Country Squire w/ Factory Rack	✓+72314
'07-09	Edge w/ Raised Rail	✓+72314
'07-09	Escape w/ Raised Rail	✓
'01-07	Escape w/ Factory Track	✓
'81-90	Escort Wagon w/ Factory Rack.	✓+72314
'97-09	Expedition w/ Factory Rack	✓

FORD (continued)		Fit
'97-09	Expedition EL w/ Factory Rack	✓[1]
'91-01	Explorer 2DR w/ Factory Rack	✓
'91-09	Explorer 4DR w/ Factory Rack	✓
'01-03	Explorer Sport 2DR w/ Factory Rack	✓
'07-09	Explorer Sport Trac w/ Factory Rack	✓
'01-05	Explorer Sport Trac w/ Factory Rack	✓[1]
'09	Flex w/ Raised Rails	✓[1]
'01-07	Focus Wagon w/ Factory Rack	✓+72314
'00	Focus Wagon w/ Factory Rack	✓[1]
'04-07	Freestar w/ Factory Rack	✓
'90-06	Taurus Wagon w/ Factory Rack	✓
'08-09	Taurus X	✓
'95-99	Windstar w/ Raised Rails	✓+72314
'98-03	Windstar w/ Factory Track	✓+72314
GEO		Fit
'96-97	Tracker 4DR (Hard Top) w/ Factory Rack.	✓+72314
GMC		Fit
'98-04	Denali w/ Factory Rack	✓
'00-04	Denali XL w/ Factory Rack	✓
'02-09	Envoy / Envoy Denali w/ Factory Rack	✓
'98-01	Envoy w/ Factory Rack	✓
'02-06	Envoy XL / Envoy Denali XL w/ Factory Rack	✓
'95-01	Jimmy 2DR w/ Factory Rack	✓
'95-01	Jimmy 4DR w/ Factory Rack	✓
'91-94	Jimmy / S-15 2DR w/ Factory Rack	✓+72314
'85-90	Jimmy / S-15 2DR w/ Factory Rack	✓+72314
'91-94	Jimmy / S-15 4DR w/ Factory Rack	✓+72314
'85-90	Jimmy / S-15 4DR w/ Factory Rack	✓+72314
'85-05	Safari Van w/ Factory Rack	✓

✓+72314 = The #72314 Rack System is needed to allow these carriers to be used. SportRack #72320 may be substituted for #72314 if available.

✓[1] = Only carriers #72003/72016 will fit this vehicle.

If additional information is needed, please call Customer Service at 1-800-561-0716.



Applications for #72020 X-Cargo Sport 20, #72016 X-Cargo X-Treme & #72003 Thule Evolution

Note: These cargo carriers can not be attached directly to vehicles not listed below. **For additional fit options, see SportRack Application Guide.**

GMC (continued)		Fit
'92-99	Suburban w/ Factory Rack	✓
'92-99	Yukon 2DR w/ Factory Rack	✓
'95-09	Yukon 4DR w/ Factory Rack (Except Denali Models)	✓
'07-09	Yukon XL w/ Factory Rack	✓
'00-06	Yukon XL w/ Factory Rack	✓
'07-09	Yukon Denali	✓
'07-09	Yukon Denali XL	✓
HONDA		Fit
'91-95	Accord Wagon w/ Factory Rack	✓+72314
'97-09	CRV w/ Factory Rack	✓
'03-09	Element w/ Factory Rack	✓
'95-09	Odyssey w/ Factory Rack	✓
'94-02	Passport w/ Factory Rack	✓
'03-09	Pilot w/ Factory Rack	✓
'06-09	Ridgeline w/ Factory Rack	✓
HUMMER		Fit
'05-09	H3 (includes Alpha Models)	✓
'09	H3T (includes Alpha Models)	✓
HYUNDAI		Fit
'97-00	Elantra Wagon w/ Factory Rack	✓+72314
'07-09	Entourage	✓+72314
'07-09	Santa Fe w/ Flush Rail	✓
'01-06	Santa Fe w/ Flush Rail	✓+72314
'05-09	Tucson w/ Complete Factory Crossbar System	✓[1]
'08-09	Veracruz	✓+72314
INFINITI		Fit
'08-09	EX 35 w/ Factory Rack	✓
'03-09	FX 35 w/ Factory Rack	✓+72314
'03-08	FX 45 w/ Factory Rack	✓+72314

INFINITI (continued)		Fit
'09	FX 50 w/ Factory Rack	✓+72314
'97-03	QX4 w/ Factory Rack	✓
'08-09	QX56	✓
ISUZU		Fit
'03-09	Ascender w/ Factory Rack	✓
'96-99	Oasis w/ Factory Rack.	✓+72314
'91-04	Rodeo w/ Factory Rack	✓
JEEP		Fit
'85-01	Cherokee w/ Factory Rack	✓
'06-09	Commander w/ Standard Crossbars	✓
'93-09	Grand Cherokee w/ Factory Rack	✓
'93-94	Grand Wagoneer w/ Factory Rack	✓
'02-09	Liberty w/ Raised Rails	✓+72314
'07-09	Patriot	✓
'84-96	Wagoneer	✓
KIA		Fit
'09	Borrego	✓
'07-09	Rondo w/ Flush Side Rails	✓[1]
'09	Rondo EX w/ Raised Rails	✓+72314
'06-09	Sedona w/ Factory Rack	✓
'02-05	Sedona w/ Factory Rack	✓+72314
'03-09	Sorento w/ Factory Rack	✓
'96-09	Sportage 4DR w/ Factory Rack	✓+72314
'01-02	Sportage Limited w/ Factory Rack	✓+72314
LAND ROVER		Fit
'95-03	Discovery Series II w/ Factory Rack.	✓+72314
'02-05	Freelander 3DR / 5DR w/ Factory Rack	✓+72314
'03-09	Range Rover w/ Factory Rack	✓
'98-02	Range Rover w/ Factory Rack	✓

✓+72314 = The #72314 Rack System is needed to allow these carriers to be used. SportRack #72320 may be substituted for #72314 if available.

✓[1] = Only carriers #72003/72016 will fit this vehicle.

If additional information is needed, please call Customer Service at 1-800-561-0716.



Applications for #72020 X-Cargo Sport 20, #72016 X-Cargo X-Treme & #72003 Thule Evolution

Note: These cargo carriers can not be attached directly to vehicles not listed below. **For additional fit options, see SportRack Application Guide.**

LAND ROVER (continued)		Fit
'03-09	Range Rover Sport w/ Factory Rack	✓
'98-02	Range Rover Sport w/ Factory Rack	✓
LEXUS		Fit
'03-09	GX470 w/ Factory Rack	✓
'96-97	LX450 w/ Factory Rack.	✓+72314
'99-07	LX470 w/ Factory Rack	✓
'08-09	LX 570 w/ Factory Rack	✓
'04-06	RX330 w/ Factory Rack	✓
'05-09	RX350 w/ Factory Rack	✓
'05-09	RX400H w/ Factory Rack	✓
LINCOLN		Fit
'03-05	Aviator w/ Factory Rack	✓
'07-09	MKX w/ Raised Rails	✓+72314
'98-09	Navigator w/ Factory Rack	✓
MAZDA		Fit
'04-07	6 Wagon w/ Factory Rack	✓+72314
'07-09	CX-9 w/ Raised Rail	✓
'07-09	CX-9 w/o Raised Rail	✓
'97-99	MPV w/ Factory Rack	✓+72314
'89-96	MPV w/ Factory Rack	✓
'91-94	Navajo w/ Raised Rail	✓+72314
'02-03	Protégé 5 Wagon w/ Factory Rack	✓
'01-09	Tribute w/ Factory Rack	✓+72314
MERCEDES-BENZ		Fit
'86-97	300 TD & TE w/ Factory Rack	✓+72314
'02-09	C-Class Wagon w/ Factory Rack	✓+72314
'98-09	E-Class Wagon w/ Factory Rack	✓+72314
'09	GLK w/ Raised Rails	✓+72314
'98-09	M-Class w/ Factory Rack	✓+72314

MERCURY		Fit
'05-09	Mariner w/ Factory Rack	✓+72314
'04-07	Monterey w/ Factory Rack	✓+72314
'96-08	Mountaineer w/ Factory Rack	✓+72314
'90-05	Sable Wagon w/ Factory Rack	✓
'87-99	Tracer Wagon	✓
'99-02	Villager w/ Factory Rack	✓
'93-98	Villager w/ Factory Rack	✓
MINI		Fit
'08-09	Clubman w/ Raised Rails	✓+72314
MITSUBISHI		Fit
'04-09	Endeavor w/ Factory Rack	✓
'92-95	Expo / Expo LRV	✓+72314
'04	Lancer Sportback w/ Factory Rack	✓+72314
'01-06	Montero w/ Factory Rack	✓+72314
'89-00	Montero w/ Factory Rack	✓+72314
'01-04	Montero Sport w/ Factory Rack	✓+72314
'99-00	Montero Sport w/ Factory Rack	✓
'97-98	Montero Sport w/ Factory Rack	✓[1]
'07-09	Outlander w/ Factory Rack	✓
NISSAN		Fit
'08-09	Armada	✓
'90	Axxess	✓[1]
'05-09	Frontier 4DR Crew Cab w/ Factory Rack	✓
'03-09	Murano w/ Factory Rack	✓+72314
'05-09	Pathfinder w/ Factory Rack	✓
'02-04	Pathfinder w/ Raised Rail	✓
'02-04	Pathfinder w/ Factory Track	✓
'87-90	Pathfinder 2DR w/ Factory Rack	✓+72314
'96-01	Pathfinder 4DR w/ Factory Rack	✓

✓+72314 = The #72314 Rack System is needed to allow these carriers to be used. SportRack #72320 may be substituted for #72314 if available.

✓[1] = Only carriers #72003/72016 will fit this vehicle.

If additional information is needed, please call Customer Service at 1-800-561-0716.



Applications for #72020 X-Cargo Sport 20, #72016 X-Cargo X-Treme & #72003 Thule Evolution

Note: These cargo carriers can not be attached directly to vehicles not listed below. **For additional fit options, see SportRack Application Guide.**

NISSAN (continued)		Fit
'99-09	Quest w/ Factory Rack	✓[1]
'08-09	Rogue	✓+72314
OLDSMOBILE		Fit
'91-04	Bravada w/ Factory Rack	✓
'91-92	Custom Cruiser Wagon w/ Factory Rack	✓+72314
'77-90	Custom Cruiser Wagon w/ Factory Rack	✓+72314
'83-94	Cutlass Cruiser Wagon w/ Factory Rack.	✓
'90-04	Silhouette w/ Factory Rack	✓
PLYMOUTH		Fit
'88-91	Colt Vista Wagon w/ Factory Rack	✓+72314
'91-00	Voyager/Grand Voyager w/ Factory Rack	✓
PONTIAC		Fit
'82-89	6000 Wagon w/ Factory Rack.	✓+72314
'01-05	Aztec w/ Factory Rack	✓
'07-09	Montana SV6 w/ Factory Rack (Canada Only)	✓+72314
'05-06	Montana SV6 w/ Factory Rack	✓+72314
'99-05	Montana w/ Factory Rack	✓
'06-09	Torrent	✓
'97-98	Trans Sport w/ Factory Rack	✓
'09	Vibe w/ Factory Rack	✓
'03-08	Vibe w/ Factory Rack	✓
PORSCHE		Fit
'03-09	Cayenne w/ Raised Rail	✓+72314
SAAB		Fit
'09	9-3 SportCombi wagon	✓+72314
'99-09	9-5 Wagon w/ Factory Rack	✓+72314
'05-09	9-7x	✓
SATURN		Fit
'00-04	LW Wagon w/ Factory Rack	✓+72314

SATURN (continued)		Fit
'05-07	Relay w/ Factory Rack	✓+72314
'02-05	Vue w/ Factory Rack	✓[1]
SUBARU		Fit
'03-07	Baja 4DR w/ Factory Rack	✓
'98-09	Forester w/ Factory Rack	✓
'08-09	Impreza / Outback Sport / WRX / STI Wagon w/ Factory Rack	✓
'02-07	Impreza / Outback Sport / WRX / STI Wagon w/ Factory Rack	✓[1]
'94	Legacy GT Wagon w/ Factory Rack	✓+72314
'89-04	Legacy Wagon w/ Factory Rack	✓
'95-99	Legacy Outback w/ Factory Rack	✓
'00-09	Outback Wagon w/ Factory Rack	✓
'02-09	Outback Sport w/ Factory Rack	✓
'06-07	Tribeca w/ Factory Rack	✓
SUZUKI		Fit
'98-02	Esteem Wagon w/ Factory Rack	✓+72314
'06-09	Grand Vitara w/ Flush Rail	✓
'99-05	Grand Vitara / Vitara 4DR w/ Factory Rack	✓+72314
'96-98	Sidekick 4DR w/ Factory Rack	✓+72314
'07-09	SX4 Hatchback	✓+72314
'07-09	XL-7 w/ Factory Rack	✓
'01-06	XL-7 w/ Factory Rack	✓+72314
TOYOTA		Fit
'03-09	4 Runner w/ Factory Rack	✓
'90-95	4 Runner 2DR w/ Factory Rack.	✓
'90-02	4 Runner 4DR w/ Factory Rack.	✓
'92-96	Camry Wagon w/ Factory Rack	✓+72314
'01-09	Highlander w/ Factory Rack	✓
'91-09	Land Cruiser w/ Factory Rack	✓
'09	Matrix w/ Factory Rack	✓

✓+72314 = The #72314 Rack System is needed to allow these carriers to be used. SportRack #72320 may be substituted for #72314 if available.

✓[1] = Only carriers #72003/72016 will fit this vehicle.

If additional information is needed, please call Customer Service at 1-800-561-0716.



Applications for #72020 X-Cargo Sport 20, #72016 X-Cargo X-Treme & #72003 Thule Evolution

Note: These cargo carriers can not be attached directly to vehicles not listed below. **For additional fit options, see SportRack Application Guide.**

TOYOTA (continued)		Fit
'03-08	Matrix w/ Factory Rack	✓
'01-09	RAV4 w/ Factory Rack	✓
'01-09	Sequoia w/ Factory Rack	✓
'04-09	Sienna w/ Factory Rack	✓
'98-03	Sienna w/ Factory Rack	✓+72314
VOLKSWAGEN		Fit
'74-81	Dasher 4DR / Wagon w/ Factory Rack.	✓+72314
'09	Jetta SportWagen / Clean Diesel TDI w/ Factory Rack	✓+72314
'01-09	Jetta Wagon w/ Factory Rack	✓+72314
'90-09	Passat Wagon w/ Factory Rack	✓+72314
'82-88	Quantum w/ Factory Rack	✓+72314
'09	Routan w/ Factory Rack	✓+72314
'08-09	Tiguan w/ Factory Rack	✓+72314
'08-09	Touareg (aka Touareg 2)	✓
'04-07	Touareg	✓
VOLVO		Fit
'79-93	240 / 260 Wagon w/ Factory Rack	✓+72314
'84-90	740 / 760 Wagon w/ Factory Rack	✓+72314
'91-97	740 / 940 / 960 Wagon w/ Factory Rack	✓+72314
'94-97	850 Wagon w/ Factory Rack	✓+72314
'00-04	V40 w/ Factory Rack	✓+72314
'05-09	V50 w/ Factory Rack	✓+72314
'98-09	V70 w/ Factory Rack	✓+72314
'98-09	V70 XC w/ Factory Rack	✓+72314
'98-00	V90 w/ Factory Rack	✓+72314
'08-09	XC70 w/ Factory Rack	✓+72314
'03-09	XC90 w/ Factory Rack	✓+72314

✓+72314 = The #72314 Rack System is needed to allow these carriers to be used. SportRack #72320 may be substituted for #72314 if available.

✓[1] = Only carriers #72003/72016 will fit this vehicle.

If additional information is needed, please call Customer Service at 1-800-561-0716.