



OWNER'S MANUAL

HARRISON SIDE TABLE

Product code: D71 M34586

UPC code: 769455 767202


Vendor Item: SS-I-139NET

Date of purchase: ____/____/____

PARTS

Read through all the instructions before beginning assembly. Unpack and identify all the parts. Place them on a flat, non-abrasive surface. Assembly by two people is recommended.

ITEM	DESCRIPTION	QUANTITY
A	Tempered Glass Tabletop with rim	1
B	Leg	3



ACCESSORIES

Ca (1)
Shelf Bracket
(3 Metal Washers and
3 Bolts attached)



Cb (1 spare)
Bolt



Cc (1)
Allen Wrench



Cd (1)
Assembly
Instructions Sheet



ASSEMBLY INSTRUCTIONS

1


Cb x 3
Bolt
(remove from shelf bracket)



Metal Washer x 3
(remove from shelf bracket)



Ca x 1
Shelf Bracket



- Don't tighten completely.
- Repeat procedure for the other two legs.

- Securely tighten all bolts.
- Turn over the whole table and keep flat.

- Your side table is now ready for use.

CARE INSTRUCTIONS

Wash with a mild solution of soap and water; rinse thoroughly. Dry completely. Do not use bleach or solvents. Cover furniture with outdoor furniture covers when not in use.

sears

Please refer to part numbers when reordering

For questions or comments about product:

Call toll-free: 1-800-457-4652

Made in / Hech en CHINA

Distributed by Sears, Roebuck and Co., Hoffman Estates, IL 60179

See our extensive assortment of outdoor living products
on-line at www.sears.com and www.kmart.com

